


There are two methods to check the product firmware version.

Checking the version on a self-test sheet

1. Load continuous paper or full-page labels.
2. While pressing the Feed button, press and hold the (power) button. Do not release the (power) button until the (power) LED starts to flash. Self-test printing begins. Check the first line of the self-test print results.



Checking the version on the printer driver

1. Display the printer driver.
2. Select the Printer Utilities tab and then click Printer Setting Utility.

The TM-C3500 PrinterSetting screen appears. The product firmware version is displayed in the "Firmware Version" field.

