

Cautions

- Printer driver screen layout

The screen layout and setting methods are changed.

[\[TM-C3500 Series User's Guide\]](#) - [\[How to Use the Printer Driver\]](#) - [\[Printer Driver Screen Configuration\]](#)

- Media Definition

The "Media Layout" settings you registered to Ver.1 cannot be used with Ver.2. When using Ver.2, register the media settings in the "Media Definition" screen.

[\[TM-C3500 Series User's Guide\]](#) - [\[How to Use the Printer Driver\]](#) - [\[Registering Paper \(Media Definition\)\]](#)

- Media arrangement

The following requirements to reduce waste for die-cut label paper and continuous paper (Blackmark) are changed.

- Length from the leading edge of the paper to the leading edge of the first black mark or label (Media arrangement when feeding media for printing from the first sheet)

- Length from the rear edge of the paper to the rear edge of the last ticket or label (Media arrangement for printing on the last sheet)

[Note]

If you use media that you have arranged to meet the requirements for Ver.1, a "MEDIA FORM ERROR" may occur.

When using Ver.2, arrange your media so that the length from the leading edge of the media to the leading edge of the first black mark or label falls within the range of 172.5 to 200 mm.

[\[TM-C3500 Series Developer's Guide\]](#) - [\[Media Design\]](#) - [\[Paper Handling to Prevent Unprinted Labels\]](#) - [\[Printing from the First Label at Paper Loading\]](#) or [\[Printing the Final Label\]](#)

Added Features

- Black and white banding will be unnoticeable

Change the "Print Quality" setting of the printer driver to "Quality (Mode2)"

[\[TM-C3500 Series User's Guide\]](#) - [\[Troubleshooting\]](#) - [\[Problems with Print Quality\]](#) - [\[White or Black Banding\]](#)

- Paper feed amount when a paper set error occurs is reduced.

When a paper set error occurs, the paper is fed until the printer stops.

You can reduce the paper feed amount by selecting the "No paper feed for positioning" option in the "Paper loading at roll paper cover dose" menu in PrinterSetting.

To access the menu, click "General" – "Printer Operation Setting" – "Paper Loading Settings" – "Paper loading at roll paper cover dose" in that order.

[\[TM-C3500 Series User's Guide\]](#) - [\[Advanced Usage\]](#) - [\[PrinterSetting Functions and Operating Procedures\]](#) - [\[How to Start PrinterSetting\]](#)

- Print area on die-cut labels is expanded

By changing dip switch 3 to ON, the print area on die-cut labels will expand.

[\[TM-C3500 Series User's Guide\]](#) - [\[Troubleshooting\]](#) - [\[Problems with Print Quality\]](#) - [\[Unintended Top and Bottom Margins are Generated\]](#)